

# PHOTON MICRO-LIGHT



Photon  
(dual batteries /  
squeeze only switch)

White, Blue and  
UV

Photon  
(single battery /  
squeeze only switch)

Red and Infrared



## Battery Replacement

1. Carefully wedge open the tab on the bottom of the Photon case using a nail file or small screwdriver.
2. Replace with one CR2032 or two CR2016 Eveready lithium coin cells (depending on model and beam color) with the plus (+) side up.
3. Close by aligning tab and snapping shut.

**Note:** In the unlikely event of water penetrating the case, simply open and dry out.

### We Take Quality Seriously

If your Photon Micro-Light fails for any reason other than abuse or battery expiration, return it for free repair or replacement to:

LRI • PO Box 58 • Blachly, OR 97412

**PHOTON** Light.com

200 W 38th Avenue • Eugene, Oregon 97405  
P. 1.877.584.6898, 541.925.3149 F. 541.484.6898  
www.photonlight.com